


Kepco Test Circuit Setup



Ramping the DC power supply from 0 to 5 volts should cause the output current meter on the Kepco to ramp from 0-50 amps.